



Single Rope Chair/Rocker

Congratulations on your purchase. You now have one of Nags Head Hammocks' innovative products! If you have any questions regarding this product, we invite you to call us 7 days a week at 800-344-6433.

Helpful tips before starting: • Get someone to help you. Some pieces are heavy and a second pair of hands always helps. • Do not tighten the bolts completely until the product is fully assembled. Some pieces are harder to fit in place and this will help. A hammer or rubber mallet is needed during assembly. • Do not over-tighten the bolts or screws. • Build your item close to where it will be used to eliminate difficulty in moving once completed. • For a uniform look, face all nuts in the same direction.



Step 1. Start by setting rollup with left side facing up. Align left arm with 3 holes as shown. FIGURE 1 Attach left arm using 3.5" hex bolt, with 1 washer per side, secure with lock washer. Do not tighten fully.




Step 2. Repeat step 1 for right side.

Step 3. Set upright, move rollup forward.


Step 4. Starting with left upright, secure in hole as shown FIGURE 2 with 3.5" hex bolt, one washer per side and secure with lock nut.




Step 5. Rotate left upright up until hole aligns with remaining hole. Secure using 4" barrel bolt assembly as shown. FIGURE 3



Parts: Chair/Rocker



Hardware



Rocker: Additional Parts




Rocker: Additional Hardware



Step 6. Repeat steps 4 and 5 for right upright.

Step 7. Insert 1 barrel bolt, per side in top hole of rollup. FIGURE 4 Align with top holes in upright. Secure rollup with 4.5" barrel bolt assembly.



Step 8. Insert and secure 4.5" barrel bolts in remaining 2 holes of rollup. FIGURE 5



Step 9. Tighten all regular bolts with 7/17" wrenches.

Step 10. Insert cup holder. FIGURE 6



Step 11. Enjoy your new Nags Head Hammocks Single Rope Chair.

If you have purchased the Single Rope Rocker, continue with the following steps:

Step 12. Turn rocker on side with left side facing up. Align runner, small end facing forward with holes at base of rocker legs. Secure with 3.5" hex bolt, 1 washer per side of runner and locker nut in front - one per hole. FIGURE 7

Step 13. Repeat step 12 for right side, only turning the rocker so that the right side is upright as you complete this step.

Step 14. Turn rocker upright and start rocking.



*Care Instruction and Tips: Great care has been put into manufacturing this item. However, it is made of high density resin and some natural esthetic imperfections and dark spots are normal and should be expected. You can wash the wood and the rope using a hose and some bleach water. You can also brush the wood to help remove dirt. *These instructions are also available at www.nagsheadhammocks.com/assembly_instructions.asp Warranty: Products of Nags Head Hammocks are guaranteed to be free of defects in workmanship or material. We will replace defective parts for free. Simply call us and we will see that you get what you need. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty nor is damage caused by normal wear, mildew, improper care including storage, maintenance, and assembly. Returns: Nags Head Hammocks has a money back guarantee. If you are not satisfied with an item, return it unused in its original packaging for a complete merchandise refund or exchange. You can return it to any store or to our warehouse, Nags Head Hammocks, 305 Industrial Bd., Greenville, NC 27834. Please include a copy of your receipt and your contact information. Nags Head Hammocks, PO Box 533, Nags Head, NC 27959*