



Congratulations on your purchase. You now have one of Nags Head Hammocks innovative products! If you have any questions regarding this product, we invite you to call us 7 days a week at 800-344-6433.

Helpful tips before starting:

- Get someone to help you. Some pieces are heavy and a second pair of hands always helps.
- Do not tighten the bolts completely until the product is fully assembled. Some pieces are harder to fit in place and this will help. A hammer or rubber mallet is needed during assembly.
- Do not over-tighten the bolts or screws.
- The pictures in our catalog can also provide help while assembling your item.
- Build your item close to where it will be used. Some items are difficult to move once completed.
- For a uniform look, face all nuts in the same direction.





DuraWood Deluxe Double Swing (NHDWDDS)

*Footstool not included



Instruction #: 5113NH, 0W.0P

The DuraWood Deluxe Double Swing comes in two boxes:

Box 1	Box 2
<p align="center">NHDWDDSARM</p>	<p align="center">NHDWDDS+Color</p>
 <p>Head pillows will ship in a separate envelop or be included inside one of the two boxes.</p>	
<p>Hardware: 3.5" Hex Head Bolts (Qty. 8) 4.75" Hex Head Bolts (Qty. 2) 5" Hex Head Bolts (Qty. 7) 5.5" Carriage Bolts (Qty. 4) Nuts (Qty. 23) Washers (Qty. 38) Tree Hooks (Qty. 2)</p>	
<p>Also needed for assembly are: Rubber Mallet or Hammer One Ratchet with a size 7/16" Socket One Key with a size 7/16"</p>	

STEP 1

Do not tighten nuts until the last step. Fix one of the two Outside Uprights on the Arm using one 3.5" Hex Bolt and one 4.75" Hex Bolt. The Upright goes inside the Arm and the 4.75" bolts affixes to the arms rest. Place the bolts facing outward. Right arm (when sitting) is shown.



STEP 2

Put the arm on the rope body using three of the 3.5" Hex Bolts. Repeat Step 1 and 2 for the other side.



STEP 3

Unroll the Rope Body and affix to front of Uprights using one of the Carriage Bolt. Insert the bolts on the lower holes. Repeat on other side.



STEP 4

Insert the Middle Upright between both Back Table Legs using two of the 5" Hex Bolt..



STEP 5

Put the Back Legs-Uprights assembly on the Swing using one 5" Hex Bolt.



STEP 6

Put the Front Table Legs on the swing using two of the 5" Hex Bolts



STEP 7

Put the table on top using using two of the 5" Hex Bolts.



STEP 8

Attach the top of the swing with 2 of the Carriage Bolts.



STEP 9

Insert the shorter side of the chain inside the upper hole. Put a washer on each side. Repeat on other side.

**STEP 10**

Insert the longer part of the chain inside the bottom hole. Put a washer on each side. Repeat on other side.

**STEP 11**

Tighten all the nuts and bolts.

STEP 12

Hang the swing in an area that is at least 8 ft deep and 7 ft wide to allow for sufficient swinging space. Drill two holes 51 inches apart using a 1/8" drill bit. Screw the hooks in place (you may use a screw driver to help turn the screw tighter).

STEP 13

Insert the drink holder cups and attach the head pillow(s).

Care Instruction and Tips:

Great care has been put into manufacturing this item. However, it is made of high density resin and some natural esthetic imperfections and dark spots are normal and should be expected. You can wash the wood and the rope using a hose and some bleach water. You can also brush the wood to help remove dirt. The side of the wood is made to be a wood look alike.

*These instructions are also available at www.nagsheadhammocks.com/nhdwdds.asp

Warning:

Always use extreme caution when putting Nags Head items up or down as some parts are heavy and can be hazardous. Get someone to help you as much as possible to prevent accidents. Make sure all bolts are tightened before usage. Do not overtighten bolts as they can break. Always supervise children when using our products. Never exceed weight limits of products. Do not jump on or use products in non-intended ways. Proper maintenance is the key to enjoying your Nags Head Hammocks product for many years. Nags Head Hammocks is not responsible for accidents.

Warranty:

Products of Nags Head Hammocks are guaranteed to be free of defects in workmanship or material. We will replace defective parts for free. Simply call us and we will see that you get what you need. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty nor is damage caused by normal wear, mildew, improper care including storage, maintenance, and assembly.

Returns:

Nags Head Hammocks has a money back guarantee. If you are not satisfied with an item, return it unused in its original packaging for a complete merchandise refund or exchange. You can return it to any store or to our warehouse, Nags Head Hammocks, 305 Industrial Bd., Greenville, NC 27834. Please include a copy of your receipt and your contact information.

Nags Head Hammocks
PO Box 533, Nags Head, NC 27959
www.nagsheadhammocks.com
800-344-6433