



## Quilted Hammock

*Congratulations on your purchase of the Quilted Hammock. We believe that you will Find it a product of unsurpassed quality and durability.*

If you have any questions regarding our products, call our toll-free consumer customer service line: **800.643.3522**

Visit our web page: [www.thehammocksource.com](http://www.thehammocksource.com)

### MAXIMUM SAFE WEIGHT LIMIT OF HAMMOCK: 450 LBS

Included with your hammock will be:  
2 – screw-eye hooks for use in post or tree installation

### Installation of Hammock

1. The space in which you plan to hang your hammock should be 18 to 24 inches greater than the overall length of your hammock. If you have any questions, please call us for assistance. **In any event, always test your hammock carefully prior to each use to make certain that it is hung securely and in safe condition.**

a. **Make certain the tree is at least 6 inches (15 cm) in diameter (posts should be at least 4' x 4') and that the wood is a hardy species such as oak or hickory. Woods such as willow, palm, or beech are very soft and may not hold the hammock when in use.** If installing the hammock into any surface other than wood, consult a professional for the proper method and the additional supplies needed for a safe installation.

b. To install the eye bolts that accompany your hammock, first drill a 1/8"-3/16" pilot hole. (Pilot hole should be as small as possible in order to ensure safe assembly and use of hammock.) Screw in the eye bolt one turn past the point that the last thread was covered. **Do not over twist the eye bolt. This may cause damage to the metal and weaken the support.**

c. Hook the free end of the chains on each side of your hammock over your newly installed hammock hooks, using the chain links to adjust height and tautness (Figure A). Once the hammock ropes have fully stretched, you may want to tweak your hammock height by further adjusting chain lengths. **DO NOT WRAP THE CHAIN AROUND THE HAMMOCK HOOK AND BE CERTAIN THAT THE CHAIN IS NOT TWISTED.** Either of these may cause the links of the chain to bend and weaken.

### Care & Maintenance:

Care and maintenance is easy. The fabric can be cleaned with water, a mild detergent, and a soft brush or cloth. Take care to protect wood parts, if possible. When you are through gently washing your hammock, rinse it thoroughly and allow it to air dry completely before using or storing.

### CAUTION:

—ALWAYS PLACE YOUR WEIGHT IN THE CENTER OF THE HAMMOCK. DO NOT SIT ON THE EDGE.

—DO NOT ALLOW CHILDREN TO USE THE HAMMOCK WITHOUT DIRECT ADULT SUPERVISION.




Figure A

### REPAIRS:

The workmanship of our hammocks is something we take pride in. If problems should arise from manufacturer's defect we will replace or repair the hammock at no charge. If the hammock is damaged by a frisky dog or squirrel, we offer the necessary repairs.

UNDER NORMAL USE, YOUR HAMMOCK WILL last for years; and, hopefully, the memories will last a lifetime. Enjoy your new hammock with our sincere gratitude.

NAGS HEAD HAMMOCKS

P.O. Box 533

Nags Head, NC 27959

1-800-344-6433

[www.nagsheadhammocks.com](http://www.nagsheadhammocks.com)

5062NH