


DOUBLE DELUXE SWING INSTRUCTIONS




NOTE. Instructions not to scale.

CHAIN SET

- CHAIN SETS: (2)
Eye Bolts, nuts, and washers attached

NOTE. Add chains after completing assembly.



HARDWARE PACK



(4) 4.5" Barrel Bolts



(2) 4" Barrel Bolts




(7) 5" Hex Bolts




(8) 3.5" Hex Bolts




(1) Allen Wrench



(6) 1" Barrel Nuts



(15) Lock nuts



(30) Washers

(2) Tree Hooks and chain sets


SUGGESTED TOOLS

- Rubber Mallet
- Adjustable Wrench
- Phillips Head Screwdriver

ASSEMBLY


STEP 1. Align left arm with swing body. Insert 3.5" Hex Bolt through washer, arm and swing body. Secure using washer and lock nut, repeat this process for all 3 holes both left and right side.

NOTE. Do **not** tighten bolts until Step 4.




ASSEMBLY

STEP 2. Position an upright as shown and secure it with (2) 3.5" Hex bolts and a washer on each side of the material. Repeat for the other side.




STEP 3. Attach front and rear table legs to the center table using (2) 5" Hex Bolts, a washer on each side of the material and a lock nut as shown.


Note : Rear legs are longer than the front.



STEP 4. Place the center table in the frame as shown, use (3) 5" Hex bolts, a washer on each side of the material and a lock nut to secure the front and rear legs to the center frame.




STEP 5. Attach center upright with (2) 5" Hex Bolts with a washer on each side of the material and secure with a locknut.



ASSEMBLY


STEP 6. Position roll-up as shown and secure it with (4) 4.5" Barrel Bolts, starting with the center upright.



STEP 7. Attach long bolt of Chain Assembly in the hole on the top of the roll-up, by first unscrewing the nut and removing 1 washer. Thread bolt with one washer through the frame and secure with washer and locknut. Repeat for the right side, then repeat for the front using holes in the frame as shown. Insert plastic drink holders.

Make sure to tighten all bolts then hang the swing using the included tree hooks or two other properly installed hooks - spacing hooks approximately 50-54" apart.

Enjoy your new Nag's Head Deluxe Double Swing!



Congratulations on purchasing this Original Nag's Head Deluxe Double Swing. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-295-0405.

INSTALLATION - Get somebody to help you, some pieces are heavy and a second pair of hands is always helpful. Do not tighten bolts until the product is fully assembled. Some pieces are harder to fit in place and this will help. A hammer or rubber mallet is needed during assembly. Do not over-tighten the bolts or screws. Build your item close to where it will be used to eliminate difficulty in moving once completed. For a uniform look, face all nuts in the same direction.

MAINTENANCE - Great care has been put into manufacturing this item. However, it is made of high density resin and some natural aesthetic imperfections and dark spots are normal and should be expected. You can wash the wood and the rope using a hose and some bleach water. You can also brush the wood to help remove dirt.


Thoroughly inspect product before each use. Periodically check bolts after assembly and re-tighten when necessary.

WARRANTY & RETURNS - Nags Head Hammocks products are guaranteed to be free of defects in both workmanship and material. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty, nor is damaged caused by normal wear, mildew, or improper care, including storage, maintenance, and assembly. If you are not satisfied with an item, return it unused in its original packaging for a complete refund or exchange. You can return it to any of our stores or to our warehouse, Nags Head hammocks, 305 Industrial Blvd., Greenville, NC 27834. Please include a copy of your receipt and your contact information.

BOX/PARTS BREAKDOWN

ARM BOX:

- (1) Left Arm Assembly
- (2) Right Arm Assembly



BODY BOX:

- (1) Top Roll-up
- (2) Outer Upright x 2
- (3) Center Upright
- (4) Center Front Leg x 2
- (5) Center Rear Leg x 2
- (6) Table Top
- (7) Body/Frame

