*If you have any questions regarding our products, call our*
*toll-free consumer customer service line:* **800.643.3522**
Visit our web page: www.thehammocksource.com

# Steel Swing Stand

*Congratulations on your purchase of the Steel Swing Stand.*
*We believe that you will find it a product of unsurpassed quality*
*and durability.*

## SPECIAL NOTE:

These assembly instructions have been developed to make it
as easy as possible for you to assemble the Steel Swing Stand by
yourself. However, there are several points during assembly of this
stand when you may find it helpful to have "an extra pair of hands" to
help you.

### Stand Units:

- (1) top support
- (1) bottom support
- (2) support tubes
- (4) legs

### Hardware Included:

- (8) plugs
- (6) carriage bolts
- (13) self-locking nuts
- (4) hex bolts
- (3) eye bolts
- (16) washers/gaskets

Tools needed to assemble your Steel Swing Stand: *2 Adjustable Wrenches*



Top Support
Eye Bolt (3x)
Hex Bolt (4x)
Support Tube
Support Tube
Carriage Bolt (6x)
Bottom Support
Leg (4x)
Plug (8x)

## ASSEMBLY INSTRUCTIONS:

1. Align two legs on one side of the bottom support. Insert a carriage bolt from the outside of the stand through the bottom hole. Secure bolt with nut and one washer. Hand tighten.
2. Insert one support tube into the bottom support. Insert carriage bolts into the remaining holes. Secure bolts with nuts. Hand tighten. Make sure washers are positioned on the same side as the nut.
3. Repeat the first two steps on the other side of the bottom support with the remaining two legs and support tube.
4. Insert eye bolts into the top support so that the "eye" of the bolts will point to the ground when fully assembled. Secure the bolts with a nut and tighten with a wrench. Make sure there is a washer on each side.
5. Place the top support onto the support tubes. Make sure the top support slides down all the way on both support tubes. Insert the hex bolts into all holes and secure with washers and nuts. Hand tighten. Make sure washers are on the same side as the nut.
6. Tighten all bolt connections on the swing stand with two adjustable wrenches.
7. Place a plug onto both ends of each leg.

### WARNING: DO NOT EXCEED LOAD LIMIT OF 600 lbs.

**DO NOT ALLOW CHILDREN TO USE THE HAMMOCK WITHOUT DIRECT ADULT SUPERVISION. DO NOT HAVE INFANTS IN THE HAMMOCK.**

### Stands should be examined periodically to ensure that:

- There are no missing plugs (rust protection).
- There is no excessive rust.

### CARE AND MAINTENANCE:

* You may want to disassemble your stand for more convenient storage during the cooler part of the year.
* To clean your stand, simply wipe it off with a soft, damp cloth; then dry it off immediately using a clean, dry, soft towel.
* If the finish on our stand gets scratched, it can be touched up easily with automotive touch-up paint, available at most auto parts stores and many department stores.
* Your stand has been finished with a long-lasting out-door-grade finish. To prolong the life of your stand even further, you can wax it every 3-6 months with automotive wax in the same manner that you would wax your car.
* Depending on your geographical location, your stand eventually may need to be repainted. To do so, first, prepare the surface of the finish by sanding it with a very fine grit sandpaper. Then, wipe it off with a soft cloth and paint the stand with a high quality outdoor-grade enamel paint, available at most hardware stores.

## WARRANTY INFORMATION:

5162 - A
10.0D